



Registering a building




Under your organisation, tap +




If your address does not appear automatically via GPS, type it in.




Check that the address is correct and tap Continue (Fortsätt).



Choose the type of building: apartment building or house.




If you choose an apartment building, you must register a flat. Choose the flat number and tap Continue (Fortsätt).




The overview shows your newly registered property and flat. Here you can add more flats in an apartment building.


Registering residents




Tap the Residents icon to see properties and their flats. Choose the property to add a resident to, then tap Add resident (Lägg till invånare).



Choose whether the role gets access to a whole building or to a single flat.




Choose a role.



Enter the person's mobile number.


Registering a mat



In the Building list view, tap the flat where the mat will be registered.




Tap the plus sign in the flat view.




The camera opens: scan the QR code. If the camera view is black, close the app and open it again.



Choose the room.




Choose where in the room the mat lies




Tap Continue (Fortsätt) to finish.

Deregistering residents or a building



Tap the Residents icon to see properties and their flats. Choose the property to deregister.

Start by deregistering the residents.



When no residents are left, tap the bin icon next to the text No users (Inga användare).




When you confirm by tapping Remove (Ta bort), the building is deleted.

About alarms

Everyone registered to a building, home or flat receives alarms and notifications. Master users receive alarms from all homes and buildings. Admins receive alarms from every mat in the building they are linked to. Users receive alarms from the flat they are assigned to.


Green = no alarms. Red = water alarm. Yellow = offline, the mat has lost its connection. Blue = temperature alarm.

With a subscription, alarms are also sent by SMS, whether or not you use the app, as long as your mobile number is assigned to a home.



1. Alarms appear in your building list. Tap the address with the alarm to see more.
2. A user sees alarms in the Private space (Privat utrymme) view. Tap the room where the alarm started.
3. Tap the alarm to see its full details.

Deleting alarms and mats



To delete local alarms, open the mat's view, tap the three dots and choose Delete alarm (Radera alarm).

If you delete a flat's alarm history, the alarms are still stored in the system under the alarm icon, which keeps the combined history of every notification across the property portfolio.

To delete a mat, select it, tap the three dots in the top right corner and choose Remove device (Ta bort enhet).

Resetting the mat

Hold down the button on the mat until the LED flashes blue.